

	Kabelkarte SR 50 B	15 sw
49 sw		15 sw ge
2 br ws		2 br ws
56 ws sw		56 ws sw
58 gr		
54 sw rt		59 b gr rt
54 sw rt		
BS br sw		BS br sw
83 R sw gn		83 R sw gn
83 R sw gn		BK sw gn
83 gr sw		49 a gr sw
30 rt gn		30 rt gn
59 rt ws		59 rt ws
59 a rt ge		59 a rt ge
83 L sw ws		BK sw ws
83 L sw ws		83 L sw ws